DēLonghi

Living innovation

Juice Extractor

JE850M

Instruction Manual

Read this instruction manual carefully before using this product.

TABLE OF CONTENTS

1. Important Safeguards 1-2
2. Parts List 3
3. Special Helpful Hints for The Best Performance 4
4. Assembly 5-6
5. Disassembly 7
6. Additional Caution 8
7. How to Cleaning 9

IMPORTANT SAFEGUARDS:

When using this electrical appliance, basic safety precautions should always be followed including the following:

a) Read all instructions before operating.

b) To protect against risk of electrical shock do not put the motor housing in water or any other liquids.

c) Close supervision is necessary when the appliance is used by or near children.

d) Unplug from outlet when not in use, before addition or removal of any parts, and before cleaning.

e) Avoid contacting moving parts.

f) Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest authorised De'Longhi Service Agent for examination, repair or electrical or mechanical adjustment.

g) The use of attachments is not recommended as they can cause fire, electric shocks or injury.

h) Do not use outdoors

i) No not let cord hang over edge of table or counter.

j) Do not let cord contact hot surface, including the stove.

K) SAVE THESE INSTRUCTIONS.

Do not use the appliance if the rotating sieve is damaged. If the supply cord is damaged, it must be replaced by the manufacturer, an authorised De'Longhi Service Agent or similarly qualified persons in order to avoid a hazard.

SAFETY INSTRUCTIONS:

a) Always make sure juicer cover is clamped securely in place before motor is turned on. Do not unfasten clamps while juicer is in operation.

b) Be sure to turn switch to OFF position after each use of your juicer. Make sure the motor stops completely before disassembling.

c) Do not put your fingers or other objects into the juicer opening while it is in operation. If food becomes lodged in opening, use food pusher or another piece of fruit or vegetable to push it down. When this method is not possible turn the motor off and disassemble juicer to remove the remaining food.

d) Do not use the appliance if the rotating sieve is damaged.

e) Unplug before cleaning and before assembling or removing parts.

f) Turn OFF before cleaning and before assembling or removing parts.

g) The cutting blade is extremely sharp so always use food pusher.

PARTS LIST:

Pusher
Top Lid
Locking Bar
Receptacle
Juice Cup
Pulp Container
Switch
Motor Housing

SPECIAL HELPFUL HINTS FOR THE BEST PERFORMANCE:

- Do not put any fruit or vegetable in your juicer until power is turned on.
- Remove large seed from fruits such as peach, mango, etc. as the seed will damage the blade of the unit.
- The juicer has two speeds. High speed is for the hard fruits and vegetables like apples, carrots etc...and low speed is for soft fruits and vegetables such as watermelon, grapes and strawberries.
- Do not use bananas or avocados as they do not contain juice and will clog juicer.
- Allow the juicer run for a few minutes before turning off to allow any excess juice to be extracted from the pulp. Wait until motor stop spinning before disassembling.
- Do not immerse the whole machine into water or liquid at any time.

ASSEMBLY:

● Step 1:

Place receptacle on the motor housing,with juicer spout facing direction of locking bar.

● Step 2:

Place filter inside receptacle, matching its bottom to the center peg connected with the motor housing.

● Step 3:

Place top lid attached on top of the receptacle.

● Step 4:

Lock chute lid into place by lifting locking bar up until it clicks into grooves located on both side of the lid.

ASSEMBLY:

● Step 5:

Make sure locking bar is in the full upright. of the locked position otherwise the safety switch will not ON

● Step 6:

Insert pusher into chute. Always use pusher to feed fruits and vegetables into unit.

● Step 7:

Place pulp container and juice cup in their positions.

● Step 8:

Fully assembled.

DISASSEMBLY:

Important Notice:Before disassembling the unit make sure you turn the power OFF and unplug the machine from the electric outlet.

- **Step 1:**

  Remove the pusher from the chute, remove the plup container and remove the juice cup.

- **Step 2:**

  Hold the top lid and pull the locking bar as shown.

- **Step 3:**

  Release the locking bar and lower it to motor housing.

- **Step 4:**

  Remove the top lid

- **Step 5:**

  Remove the receptacle and the filter from the motor housing.

ADDITIONAL CAUTION:

1. Be careful, when cleaning the blade and teeth on the filter as these are very sharp.

2. You may put a plastic waste bag into the pulp container for easy cleaning.

3. Use filter brusher to clean the blade and teeth.

HOW TO CLEANING:

- Turn off the power switch and wait until the motor completely stops.
- With dry hands, unplug the power cord from electrical outlet.
- Disassemble the juicer as disassembly as per instructions on page #7
- Clean all other parts except the motor housing, in warm, soapy water. A mild detergent is recommended. Rinse well and dry thoroughly. The stainless steel receptacle and filter are dishwasher safe. Never submerge the motor housing into water or liquids. Plastic components are advised to be placed in the top basket of your dishwasher or hand washed.

The motor housing is not dishwasher safe.

- While the unit is unplugged, wipe base with a soft damp cloth or sponge. Do not submerge motor base in water or liquids. Do not spray with water or any other liquid.
- To clean the filter and blade, hold them under clean running water. Use a soft-bristled dish washing brush gently to completely clean pulp from filter and blade disc.

  Rinse the filter from the outside under running water.
- Dry all parts thoroughly then assemble the juicer and turn the power ON to spin out any excess water in the filter and receptacle.
- Make sure unit and parts are completely dry then store in a cool, dry place.

STEP 7A OF ASSEMBLY JE850M

IMPORTANT SAFETY FEATURE

Male connector at base of pulp collection container must make positive connection with the microswitch inside the slot at the base of the motor housing before unit is able to be activated.
This safety feature eliminates the chance of pulp being expelled without the pulp collection container in correct position.

Male Connector